


Quick Start Guide

Conference Rooms A/B/C

Tap **Splash Screen** to Start Room Functions


HOME SCREEN



- 1 Select to send signal to Display for Presentation, Web Conferencing, or Cable TV
- 2 Select Audio signal
- 3 Select to manually turn Display on/off
- 4 Select for Camera Controls
- 5 Select for TV Controls

Note: Available Sources for both Video and Audio will vary depending on Room Configuration. To combine or separate rooms, use the Master Control Panel located in the AV Rack.

PRESENTATION



- 1 From the **Home Screen**, Select **Video Source**
- 2 Fa La` ` WfS>Sbfabl eWwF: 6? ;
S` V La` ` Wf`Sbfab ge[Y: 6? ;
5ST`V`
- 3 Fa BSfUZ S` 3gj [TScK 6VW[UweWwF
6? BSfUZ BS` W`
- 4 8adFHieWwF Fg` Wd





For Support


Call 1-888-454-6863, Option 2 or email support@cenero.com

For specific questions regarding service plans, contact your Managed Service Specialist.






IN-ROOM PRESENTATION

- 1 From the Activities Menu, select **Present** .
- 2 Select **HDMI** and connect an HDMI cable to your laptop. Your presentation will appear on the display.
- 3 Select **Stop**  to end the presentation.




WEB CONFERENCING

- 1 From the Activities Menu, select **Present** .
- 2 Select **HDMI 1** as the source.
- 3 Connect both the **USB** and **HDMI cables** to your laptop.
- 4 From your laptop, open the invitation or web conferencing software and **join the meeting**.
- 5 When prompted, or in the settings, select the **Room** options for the **Speaker, Microphone, and Camera**.
- 6 Select the camera icon to open the camera controls. See *Camera Controls* below for more information.



CAMERA CONTROLS

- 1 From the **Web Conferencing Source Menu**, select the camera icon.
- 2 Use the **+/- buttons to zoom in/out**. Use the **^ buttons to pan/tilt**.
- 3 Select a **camera preset position**. To save a new camera position as a preset, press and hold a preset number.
- 4 Select the green **X** to **return to the Home Screen**.



For Support

Call 1-888-454-6863, Option 2 or email support@cenero.com

For specific questions regarding service plans, contact your Managed Service Specialist.




ADVANCED CONTROLS

To access the **Advanced Controls**, select **ADVANCED** from the **Activities Menu**.

Shutdown

- 1 To override the automatic shutdown, slide the blue indicator to **turn automatic shutdown On or Off**.
- 2 Use the controls to **change the automatic shutdown time**.
- 3 Select the green **X** to **return to the Home Screen**.



For Support

Call 1-888-454-6863, Option 2 or email support@cenero.com

For specific questions regarding service plans, contact your Managed Service Specialist.

