


# Quick Start Guide

# Master Control


Tap **Splash Screen** to Start

## ROOM SELECTION



Select **Room**

## HOME SCREEN



- 1 Select **Select Display Controls** to turn on/off individual displays or change display source
- 2 Select **Room Configuration** to combine or uncombine Conference Rooms A,B,C.
- 3 Select **Video Routing** for advanced routing control allowing multiple sources to appear on different displays.
- 4 Select **Audio Routing** for advanced routing control allowing multiple sources to route to multiple rooms




### For Support

Call 1-888-454-6863, Option 2 or email [support@cenero.com](mailto:support@cenero.com)

For specific questions regarding service plans, contact your Managed Service Specialist.




# ROOM CONFIGURATION



- 1 From the Home Screen, select Room Configuration.
- 2 Select to combine Conference **Room A and Conference Room B**.
- 3 Select to combine Conference **Room B and Conference Room C**.
- 4 Select both Combine icons to combine **Conference Room A,B, and C**.
- 5 Select to return to Home Screen.

*Note: Rooms can only be combined when not in use. Room Control must be off. When system reboots, last Room configuration remains until changed again on the Master Control Panel*

# VIDEO ROUTING



- 1 From the **Home Screen**, Select **Video Routing** for advanced routing control allowing multiple sources to appear on different displays.
- 2 Select **Source**
- 3 Select Destination **Display(s)**




**For Support**  
Call 1-888-454-6863, Option 2 or email [support@cenero.com](mailto:support@cenero.com)

**For specific questions regarding service plans,** contact your Managed Service Specialist.




# AUDIO ROUTING



- 1 From the **Home Screen**, Select **Audio Routing** for advanced routing control allowing multiple sources to route to multiple rooms
- 2 Select **Source**
- 3 Select **Destination(s)**

# DISPLAY CONTROLS



From the **Home Screen**, Select Display Controls to turn on/off individual displays or change display source.



**For Support**  
 Call 1-888-454-6863, Option 2 or email [support@cenero.com](mailto:support@cenero.com)  
**For specific questions regarding service plans,** contact your Managed Service Specialist.

